

Seven Hole Cord Foot

Use the Seven Hole Cord Foot for easily adding a finishing touch the edges of your project(s). In spite of the name, you can use as many or as few of holes in the foot to apply narrow cords or trims to any project:

To name a few, the foot can be used to apply pearl cotton, pearl crown rayon, several strands of sewing or embroidery thread, thin yarns, or chain made right from your serger. Anything that will fit easily into the holes of the foot will work.

Combine various colors of your chosen cord and needle thread to obtain very exciting results.

Use the foot, cords, and decorative stitches on your sewing machine to:

Cover raw edges of a design with straight or gentle curves.

Apply a neat finish to hems.

Simply as a decorative stitching for cool effects on a ready to wear garment.

Create one-of-a-kind trims and stitch them in place in one step

Couch or stitch up from one to seven decorative threads at once for quick embellishment. Decorative Stitch or zigzag, width to stitch over threads

How to use the Seven Hole Cord Foot:

1. Thread decorative thread into holes from the top of the foot. The more holes you thread, the wider the decorative embellishment. Wrap lengths of thread on an empty spool to prevent tangles.
2. Snap on 7-Hole Cord Foot. Place threads under the foot.
3. Mark a design on your fabric, stabilize as needed, sew. The decorative threads will be stitched down creating a beautiful braid embellishment.
4. Stabilize as needed.

Decorate anything: Here is some of my ideas - What's your idea?

Embellish...jackets, vests, dresses, blouses, and edges of sleeves, pillows, quilt blocks. Decorate hems and edges of curtains, valences.

Edges of napkins.

Use your machines decorative stitches to make your trim extra special.

Join the raw edges along two sections of woven fabrics for a decorative seam without the bulk of a seam allowance.

