

Yarn Couching Foot

Use the Yarn Couching Foot for easily adding a unique texture to any number of projects.

This foot can be used in most Husqvarna Viking sewing machines for free motion stitching yarn in any desirable pattern. If you own a Fab-U-Motion, smooth and even free motion stitching is at your finger tips (literally).

Additionally, the yarn couching foot can be used with specialized embroidery patterns available from Husqvarna Viking; however, if you have the 4D Embroidery Professional software it is easy to create many more yarn couching designs from simple pictures and/or line drawings that can be downloaded or scanned into your computer.



Use commercial yarns or make your own:

You can get especially creative and make designer yarns with your serger. Set your serger for a 3-Thread rolled edge and create a long chain of fabulous yarn from ordinary sewing thread. Mix different colors of thread for even more interesting color and effects.

If desired, make your serger yarn thicker by serging over your chain again.

Inside the package you will find:

Two different feet

One is used for smaller diameter yarns.


The other is used for thicker diameter yarns.

Two Yarn Guides

One set for most Husqvarna Viking Machines.

The other set for Sapphire and Diamond Machines.

Threader



Continued on next page...

How to use the Yarn Couching Foot

1. Thread your machine as you normally would with thread to match your yarn or clear invisible thread.
2. Snap the yarn guides into the slots on the back of your sewing machine (near the handle).
3. Pull off a pool of yarn from the skein (or ball) and lay behind your sewing machine.
4. Thread the yarn through the guides, then using the threader, thread one of the feet that will allow the yarn to flow easily in the hole of the foot. Snap the foot onto the machine.
5. Set your machine with a straight stitch and begin free motion yarn couching or start the an embroidery design.

Important: Keep it loose - in order to keep unstitched (couched) areas from occurring, it is necessary to always keep a pool of yarn behind the machine at all times (see illustration). As the pool begins to get used up, pull off more from the skein.

Stabilize if needed.

Decorate anything: Here is some of my ideas - What's your idea?

- Embellish...jackets, vests, pillows, quilt blocks.
- Decorate the borders of pillows, quilts, wall hangings.
- Free motion a name on a christmas stocking.
- A fancy trim on the bottom of curtains or towels.

